


# UNION À BOYAU MÂLE NPT

## HOSE BARB MALE NPT COUPLER

1/8 - 3/16 - 1/4 - 5/16 - 3/8 - 1/2 - 5/8 - 3/4 - 1

UNION À BOYAU MÂLE NPT HOSE BARB MALE NPT COUPLER		Diamètre du boyau <i>Hose diameter</i>	Filet NPT <i>NPT Thread</i>
	FIT-125-2A	1/8	1/8
	FIT-125-2B	1/8	1/4
	FIT-125-3A	3/16	1/8
	FIT-125-3B	3/16	1/4
	FIT-125-4A	1/4	1/8
	FIT-125-4B	1/4	1/4
	FIT-125-4C	1/4	3/8
	FIT-125-4D	1/4	1/2
	FIT-125-5A	5/16	1/8
	FIT-125-5B	5/16	1/4
	FIT-125-5C	5/16	3/8
	FIT-125-6A	3/8	1/8
	FIT-125-6B	3/8	1/4
	FIT-125-6C	3/8	3/8
	FIT-125-6D	3/8	1/2
	FIT-125-6E	3/8	3/4
	FIT-125-8B	1/2	1/4
	FIT-125-8C	1/2	3/8
	FIT-125-8D	1/2	1/2
	FIT-125-8E	1/2	3/4
FIT-125-10C	5/8	3/8	
FIT-125-10D	5/8	1/2	
FIT-125-10E	5/8	3/4	
FIT-125-12C	3/4	3/8	
FIT-125-12D	3/4	1/2	
FIT-125-12E	3/4	3/4	
FIT-125-16E	1	3/4	
FIT-125-16H	1	1	